

## Gecko LCD Program card User manual

Gecko LCD Program card can be used to set up Gecko series brushless ESC produced by ZTW Model for RC aircraft and RC car. Users can choose their desired parameter at any time.

### It has 2 use methods as follows:

- Working as an individual device to set the parameters of ESC.
- Working as a USB adapter to link the ESC with PC, to update the firmware of ESC and set the parameters of ESC on PC.

### Specification:

Dimension: 91mm\*54mm\*18mm (L\*W\*H)

Weight: 68g

Power supply: DC 5.0V~12.0V

### How to connect the LCD program card:

- Disconnect the battery from the ESC;
- Disconnect the signal wire of the ESC from the receiver; then plug it into the socket marked with (V ⊕ ⊖ )
- Connect the battery to the ESC and turn on the ESC.
- If the connection is correct, the following message(ZTW Gecko +Version+Date)will be displayed on the LCD screen. Press any buttons, the following message (Ready to connect ESC) will be showed on the LCD Screen. It signifies that the data connection between LCD and ESC is establishing.  
If the data connection between LCD and ESC is failed, the LCD Screen is always showing (Ready to connect ESC); Please check whether the signal wire is connected correctly and repeat step1,2 ,3.
- If the connection is established successfully, the first programmable item will be displayed on LCD screen. It's ready to set the parameters now.

**Note1:** Please strictly connect according to the above sequence. The sequence of step 2 and step 3 can not be reversed. Otherwise, the LCD program card can not work properly.

**Note2:** A separate power is needed if the ESC is without BEC.


Connect an additional power (5-12V) to the socket marked with ( ⊕ ⊖ ) on the left of the LCD program card for power supply. Please be sure that the polarity is connected correctly.

Plug the signal wire into the socket marked with (V ⊕ ⊖)first. Then connect an additional power (5-12V) to the socket marked with ( ⊕ ⊖ ). Then switch on the ESC. If the sequence is wrong, LCD will not work properly.

**Note3:** The power supply should be lower than 12V, or the program card will be damaged.

### Operation:

**\*Working as an individual device to program the ESC, the function of the buttons are as follows:**



**“Menu”:** Change the programmable items circularly;

**“Value”:** Change the parameters of each programmable item circularly


**Note:** Keeping the “Menu” or “Value” button holding can select the desired parameters quickly.

**“Reset”:** Return to the default settings

**“OK”:** Save the current parameters into the ESC. If you don't press “OK” button, the customized settings will not be saved and updated into the ESC. If you just press “Menu” button, the customized settings are just saved into the program card, not into the ESC.

**E.g.:** Firstly, enter the interface of a customized programmable item (e.g.: cut-off voltage 3.2/cell); Secondly, press “Value” button to select the parameters; At last, press “ok” button to save the parameters in the ESC.

**\*Working as a USB adapter to link the ESC with a PC to update the firmware of ESC and set the parameters on PC.**



Shenzhen ZTW Model  
Science & Technology CO., Ltd

c/o www.hrcDistribution.com

c/o www.hrcDistribution.com

E-mail: info@hrcDistribution.com